

Lifting unwinding handling

Assembly P800-P400



Pos. 1: Insert crosspiece 3 into supports 1 and 2



Pos. 2: Go to the reel



Pos. 3: Insert crosspiece 4 into supports 1 and 2



Pos. 4: Choose spacers to suit the ϕ



Pos. 5-6: Insert and align the rotation pin



Pos. 6



Pos. 7- 8: Formation of handlebar with levers.



Pos. 8



Pos. 9-10: Insert the levers into the spacers, find the pin and push downwards.



Pos. 10



Always engage the safety latch

Equipment for yard and internal

 www.si-ma.eu 

Design and quality made in Italy